

2018 Interconnect Errata

1. Always check for exposed wire or ripped wire on all black cable.
2. Be prepared to resize cables and reinstall connectors to reduce slack on the car
3. Order more DT06 connectors, especially the DT06-4S and DT06-6S
4. Re-do all can cables (W31). They are currently two different cables (2 3-conductor cables) that are tied together. Change to 1 6-conductor cable (14 AWG)
5. Order more DT06 female pins (16-20 AWG and 14-16 AWG. The 14-16 AWG pins have a green stripe)
6. There were issues with the grounding braiding for the orange cables with the amphenol powerlok connectors. If issues with grounding, order more Amphenol powerlok connectors (301 series, right angle, 70 mm²) and re-do the braiding. If braiding is ripping, start over.