

# CellMan Errata

1. The 4-pin connector (J1) should be changed to two 2-pin connectors. This is to separate the high current Vseg + and Vseg - connection with the data out and data in (Cn and Sn respectively).
2. Add a current sensor in the PCB to measure the charging current
3. Position the connectors so that they are not too close to the other connectors on the PCB