


Battery Pack Resistance Measurements

All voltage measurements taken with 2.00 Amp current

Contact Measurements	Voltage (μV)	Resistance (μohms)	Component Measurements	Voltage (μV)	Resistance (μohms)
AB	83	41.5	CD	275	137.5
BC	12	6	UV	519	259.5
DE	8	4	YZ	330	165
EF	75	37.5	G	18	9
FG	173	86.5	I	17	8.5
GH	18	9	K	19	9.5
HI	71	35.5	M	20	10
IJ	27	13.5	O	19	9.5
JK	95	47.5	Q	257	128.5
KL	11	5.5	S	27	13.5
LM	28	14	E	37	18.5
MN	59	29.5	B	43	21.5
NO	68	34	F	8	4
OP	60	30	H	11	5.5
PQ	145	72.5	J	4	2
QR	60	30	L	7	3.5
RS	59	29.5	N	9	4.5
ST	8	4	P	8	4
TU	16	8	R	6	3
VW	10	5	SE	1368	684
WX	16	8	S	25	12.5
XY	35	17.5	Full Fuse Block	559	279.5
ZA2	25	12.5	X	23	11.5
A2B2	46	23	A2	39	19.5
AB2 (full pack)	2845	1422.5			



A

B2

B

F

E

I

M

Q

A2

G

K

O

S

D (AIR -)

H

J

L

N

P

R

Z (AIR +)

Y (AIR -)

C (AIR +)

T

U

W

V

X (Fuse Air Bridge)